

H382914 WILT CHANDELIER

ASSEMBLY AND MOUNTING INSTRUCTIONS

GENERAL

- WARNING-DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. TURN OFF THE ENTIRE ELECTRICAL CIRCUIT TO WHICH THE LIGHTING FIXTURE IS ATTACHED
- INSTALLATION AND MAINTENANCE OF THIS FIXTURE SHOULD BE COMPLETED BY A LICENSED ELECTRICAN
- FAILURE TO INSTALL FIXTURE CORRECTLY COULD RESULT IN SERIOUS INJURY OR DEATH
- READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION.

- IF AN EXISTING FIXTURE IS BEING REPLACED, REMOVE IT AND NOTE TO WHICH WIRE IN THE OUTLET BOX THE ORIGINAL FIXTURE WAS ATTACHED.
- BEFORE DISCARDING THE CARTON DOUBLE CHECK THE PACKAGING TO MAKE SURE ALL PARTS HAVE BEEN FOUND.
- THIS FIXTURE WAS DESIGNED TO BE MOUNTED TO AN OCTAGON OUTLET BOX. THE BOX MUST BE SECURELY MOUNTED TO THE STRUCTURE OF THE BUILDING.

INSTALLATION

STEP 1. STEP 2. STEP 3.	Thread lead ground wire through pipe stem and twist tightly onto fixture body. Keep adding additional stems required. Install the canopy to the fixture by using the connector, washer and hex nut. Determine the location for the lamp. Using the mounting	STEP 8.	fixture base to neutral (usually white) outlet wire. Fasten both wires together with a plastic wire nut and tightly wrap the wire nut with electrical tape. Repeat the previous step with the hot (black wires). Make sure there are no exposed wires or strands that could cause a dangerous short circuit. FAILURE TO CONNECT THE APPROPRIATE WIRES CORRECTLY COULD RESULT IN SEROIUS INJURY OR DEATH! Carefully place connections back into the outlet box. Mount the canopy to the mounting plate and secure with end nut. Install the lamps. The fixture is rated for 25 watt type G16.5 lamp. DO NOT EXCEED RECOMMENDED WATTAGE!
0.2. 0.	plate as a template, mark the location of the holes for the wall anchors.		
STEP 4.	Drill the appropriate size holes for the wall anchors. (the holes should be slightly smaller than the size of the anchors.) Install the wall anchors to the hole.	STEP 9. STEP 10.	
STEP 5.	Attach the mounting plate to the outlet box. Screw in the wood screw to the anchors.	STEP 11.	
STEP 6.	Fasten green ground wire to ground wire from the wall outlet box (usually green or copper color) or connect		

STEP 12.

STEP 7.

The fixture can be controlled by a wall dimming device. Only use triac/electronic dimmer. Make sure carton is marked for use with LED compact fluorescent-incandescent light source only. These can be

provided by your local electrical distributor, home center, or hardware store.

Restore power to the circuit at breaker or fusebox.

CLEANING

Please clean with a soft, dry cloth ONLY! Do not use cleaning products.


ground wire to green screw on the mounting plate.

Connect the neutral (white) fixture wire coming from the





ASSEMBLYANDMOUNTINGDIAGRAM



WIRE NUT/TAPINGDIAGRAM

